



## 7. Instructions for System Configuration

### 7.1 Adjustment of Sewing Speed (parameter No.1, 4, 27-28, 50)

1) Highest speed of free-style sewing (parameter No.1)

Setting of the highest speed of treadle under free-style sewing mode, the max value is subject to parameter No.50.

(Note) lifetime of the sewing machine may be reduced by unnecessary high speed

2) Setting of preset sewing speed (parameter No.4)

Parameters of various preset sewing speeds

3) Low speed setting (parameter No.27)

Treadle's starting and running speed. It will be easy to conduct needle compensation with treadle

4) Adjustment of the speed adjustment performance of treadle(parameter No.28)

User can customize speed adjustment performance of treadle, bigger parameter leads to higher acceleration of treadle, otherwise lower. Too big value may make working uncomfortable; too small may fail the highest speed set.

Increase the parameter if treadle is unable to reach the highest speed.

### 7.2 Soft Start (parameter No.2-3)

Top stitches and bottom stitches of starting sewing may be unable to link if needle distance is too short or needle is too thick, which can be improved by limiting the highest starting sewing speed.

No.2 setting of needle number of soft start

0 Soft Start invalid

1~9 needle number of soft start, i.e. limit speed with certain needle number under starting sewing mode

No.3 setting of soft start speed

### 7.3 Setting of Needle positioning (parameter No.40)

1) Selection of upper and lower needle position

By default, the 1<sup>st</sup> key on the lower left controls stopping needle position, corresponding upper figure display the value set

0 upper needle position

1 lower needle position

2) Adjustment of lower needle position(parameter No.40)

Setting of lower needle position, deviation angle relative to upper needle position

### 7.4 Sewing Mode setting (parameter No. 5-13)

Special pattern may be realized by setting parameters.

1) selection of sewing mode(parameter No.5)

Free-style sewing: Able to keep running after treadle has been pressed, no needle number will be counted.

a) Preset sewing: the machine automatically stop when reach certain needle number, stopping times (parameter No.6) and needle number (parameter No.7-12) of stopping can be set.

b) Plain sewing: stopping needle position is free, no needle number will be counted, reinforcing-sewing mode invalid, manual reverse-sewing and automatic pressor foot lifting is available. This mode will be useful if the synchronizer of machine head is damaged.

2) setting of number of preset sewing sections and needle of each section(parameter No.6-12)

Section number for preset sewing (parameter No.6): 1~7; needle number for each section (parameter No.7-12): 1~99.

3) trigger function of preset sewing (parameter No.13)

Decide whether sewing will be completed without stop at each section under preset sewing mode. Machine can be stopped at each section during running if this function is invalid.

4) setting of thread-cutting

By default, the 2<sup>nd</sup> key on the lower left control thread-cutting function, corresponding upper figure display the value set.

0 thread-cutting unavailable

1 thread-cutting available

### 7.5 Pressor Foot Lifting Mode setting (parameter No.15)

Set the operation mode of the magnet of pressor foot lifting.

0 magnet operation unavailable

1 Only treadle command can conduct pressor foot lifting

2 automatic pressor foot lifting after thread-cutting

3 treadle operation, automatic operation after thread-cutting

4 automatic operation after machine stopping and thread-cutting

5 treadle operation, automatic operation after machine stopping and thread-cutting

(Note) set parameter No.25 to 0 if the magnet of pressor foot lifting is unavailable

-5-

### 7.6 Treadle Setting after Thread-cutting (parameter No.16)

Move treadle to thread-cutting status after thread-cutting is completed to send pressor foot lifting command setting.

If parameter No.15 is set to 1, 3, 5, then pressor foot lifting will be executed.

This function is used to facilitate pressor foot lifting after thread-cutting.

### 7.7 Automatic Top Positioning When Powered-On (parameter No.20)

When powered on, the machine head will automatically move to upper needle position, which can facilitate sewing.

No action if needle position is around upper needle position.

### 7.8 Roll-over Protection (parameter No.21)

Lock machine's functions to prevent unexpected accident when scissors did not return. Parameter No.21 controls types of roller-over signals.

When machine Lock protection, the digital tube on the upper left 1 of the operation panel of chassis will display roller-over picture.

### 7.9 Sewing Piecework (parameter No.23-24)

Counts will increase when thread-cutting is over to calculate finished sewing working procedures.

If No.23 is set to 1, piecework is available; if set to 0, piecework is unavailable.

No.24 display piecework number, press parameter value to clear piecework number for recounting.

### 7.10 adjustment stands tread cutting for pressor foot lifting.( No. 30-34)


No.30 thread-cutting delay time ttd: After the shutdown began moves to the next scissors time

No.31 thread-cutting action time tto: Action under the scissors of time

No.32 f For the delay time line twd: Under the scissors for action to end the time-start movement

No.33 For the delay time line e two: Time line for action

No.34 pressor foot lifting delay time tfd: Action Line for the end of foot movements to raise the pressure of time



### 7.11 Pressor Foot Lifting Hold Time setting (parameter No.37)

Adjust the hold time of pressor foot, long time operating can reduce the lifetime of magnet.

After pressor foot is lifted, magnet will be automatically stopped to lower pressor foot after the time set by No.37.

### 7.12 Sewing with Delayed Pressor Foot (parameter No.38)

When the magnet of pressor foot lifting operates, press treadle. Since it takes time for magnet to release, sewing machine may have begun running before pressor foot press materials firmly, affecting sewing effects. Parameter can be used to compensate the time for pressor foot lifting to release.

-6-

## 8. Error Code Table

Error codes	Contents	Possible reasons for the failure	Checking and treatment
E011 E012 E013 E014	electric engine signal error	Motor position sensor signal failure	If electric engine plug is well contacted if electric engine signal detecting device has been broken if sewing machine handwheel correctly installed
E021 E022 E023	electric engine overload	motor stall electric engine overload	If electric engine plug is well contacted if machine head or thread-cutting mechanism has been blocked completely if materials are too thick Electrical signal detection signal whether the normal
E101	Hardware drivers fault	Current detection of non-normal Driving through the device	Current detection loop system is working properly Whether the damage to the device driver
E111 E112 E113	Voltage too high	High-voltage reality Brake failure loop Motor testing is wrong	If the voltage on the inlet wire is too high Braking resistance is the normal work Whether the system voltage detection circuit the normal work
E121 E122	Voltage too low	Actual low voltage Voltage detection is wrong	If the voltage on the inlet wire is too low Whether the system voltage detection circuit the normal work
E131	Circuit fault detection circuit	Current detection of non-normal	Current detection loop system is working properly
E141	Failure to read and write data system	Non-normal data systems to read and write	Current detection loop system is working properly Whether the data chip damage
E151 E152	magnet error	Electromagnet return flow Electromagnet non-normal conduction	If machine head magnet suffers short circuit Electromagnet circuit is working properly
E201	Motor current excessive	Current detection of non-normal The normal functioning of non-motor	Current detection loop system is working properly Electrical signal is normal
E211 E212	Abnormal electric engine operation	Abnormal electric engine operation	If electric engine plug is well contacted If electric engine signal is matched
P.oFF	Power-fail	Power-down	Wait for power supply to resume
LED1 Animation	Refill oil	Shear-effective safety switch	Scissors in the back

Note: consult technical support if errors still exist.

-7-

## 9.PACKING LIST

### WR509/WR50U PACKING LIST V1.2

Number	Products name	Amount	product specification	Confirm	Remarks
1	Ball joint link	1			
2	Electric control cabinet	1	WR509/WR50U		
3	Operating box	1	EP-001		containing its support
4	Screw for electric control cabinet fixing	3	M5×30		Outside hexagon flange head self-drilling tapping screws
5	Screw for pedal fixing	3	M5×23		Outside hexagon flange head self-drilling tapping screws
6	Instruction book	1			
7	Conformity certification	1			
8	Banding rope		CV-160L		

-8-